

**Product** 22154**Number:****Order** FO25/835/XPS/ECO3**Abbreviation:**

General 25W, 36" MOL, T8 OCTRON XPS Extended Performance Super
Description: fluorescent lamp, 3500K color temperature, rare earth phosphor, 85 CRI, suitable for RS or IS operation, ECOLOGIC®3

Product Information

Abbrev. With Packaging Info.	FO25835XPSECO3 30/CS 1/SKU
Actual Length (in)	35.78
Actual Length (mm)	908.81
Average Rated Life (hr)	40000
Base	Medium Bipin
Bulb	T8
Color Rendering Index (CRI)	85
Color Temperature/CCT (K)	3500
Diameter (in)	1.098
Diameter (mm)	27.90
Family Brand Name	OCTRON® 800 XPS ECOLOGIC®3
Industry Standards	ANSI C78.81 - 2001
Initial Lumens at 25C	2200
Mean Lumens at 25C	2070
Mean Lumens at 35C	2090
Nominal Length (in)	36.000
Nominal Length (mm)	914.40
Nominal Wattage (W)	25.00
Life at 3 hrs./start on IS ballasts	24000
Life at 12 hrs./start on IS ballasts	40000
Life at 3 hrs./start on PRS ballasts	40000
Life at 12 hrs./start on PRS ballasts	42000



Footnotes

- The 40,000 hour average rated life of OCTRON® 800XP®, XP/SS and XPS lamps is based on operation at 3 hours per start on a QUICKTRONIC® programmed rapid start ballast. Average rated life is 42,000 hours at 12 hours per start on a programmed rapid

start ballast. On an instant start ballast, the average rated life is 40,000 hours at 12 hours per start, and 24,000 hours at 3 hours per start.

- Approximate initial lumens after 100 hours operation.
- The life ratings of fluorescent lamps are based on 3 hr. burning cycles under specified conditions and with ballast meeting ANSI specifications. If burning cycle is increased, there will be a corresponding increase in the average hours life.
- Minimum starting temperature is a function of the ballast; consult the ballast manufacturer.
- OCTRON lamps should be operated only with magnetic rapid start ballasts designed to operate 265 mA, T-8 lamps or high frequency (electronic) ballasts that are either instant start, or rapid start, or programmed rapid start specifically designed to operate T8 lamps. OCTRON lamps may be operated on instant start or programmed rapid start ballasts with ballast factors ranging from a minimum of 0.71 to a maximum of 1.20 at the nominal ballast input voltage (see ballast specs for details). When OCTRON lamps are operated in the instant start mode, the two contacts (bi-pin lamps) of each rapid start lampholder/socket should be connected to each other or use "shunted" circle I lampholders/sockets for instant start bi-pin lamps. Always disconnect power before servicing installations and wire per the balla schematics and National Electric Code.
- SYLVANIA ECOLOGIC fluorescent lamps are designed to pass the Federal Toxic Characteristic Leaching Procedure (TCLP) criteria for classification as non-hazardous waste in most states. TCLP test results are available upon request. Lamp disposal regulations may vary, check your local & state regulations. For more information, please visit www.lamprecycle.org