

**Product** 21999**Number:****Order** FO32/741/ECO**Abbreviation:**

General 32W, 48" MOL, T8 OCTRON fluorescent lamp, 4100K color
Description: temperature, rare earth phosphor, 78 CRI, suitable for IS or RS operation, ECOLOGIC

*** Full Case Required****Product Information**

Abbrev. With Packaging Info.	FO32741ECO 30/CS 1/SKU
Actual Length (in)	48.000
Actual Length (mm)	1219.20
Average Rated Life (hr)	20000
Base	Medium Bip in
Bulb	T8
Color Rendering Index (CRI)	78
Color Temperature/CCT (K)	4100
Diameter (in)	1.098
Diameter (mm)	27.90
Family Brand Name	Octron® 700, Ecologic
Industry Standards	ANSI C78.81 - 2001
Initial Lumens at 25C	2600
Mean Lumens at 25C	2390
Nominal Length (in)	48.000
Nominal Length (mm)	1219.20
Nominal Wattage (W)	32.00
Life at 3 hrs./start on IS ballasts	24000
Life at 12 hrs./start on IS ballasts	28000
Life at 3 hrs./start on PRS ballasts	30000
Life at 12 hrs./start on PRS ballasts	35000

**Footnotes**

- e 30,000 hour average rated life of OCTRON® 700 Series lamps is based on operation at 3 hours per start on a QUICKTRONIC® programmed rapid start ballast. Average rated life is 35,000 hours at 12 hours per start on a programmed rapid start ballast. On an instart start ballast, the average rated life is 28,000 hours at 12 hours per start, and 24,000 hours at 3 hours per start.

- Approximate initial lumens after 100 hours operation.
- The life ratings of fluorescent lamps are based on 3 hr. burning cycles under specified conditions and with ballast meeting ANSI specifications. If burning cycle is increased, there will be a corresponding increase in the average hours life.
- Minimum starting temperature is a function of the ballast; consult the ballast manufacturer.
- OCTRON lamps should be operated only with magnetic rapid start ballasts designed to operate 265 mA, T-8 lamps or high frequency (electronic) ballasts that are either instant start, or rapid start, or programmed rapid start specifically designed to operate T8 lamps. OCTRON lamps may be operated on instant start or programmed rapid start ballasts with ballast factors ranging from a minimum of 0.71 to a maximum of 1.20 at the nominal ballast input voltage (see ballast specs for details). When OCTRON lamps are operated in the instant start mode, the two contacts (bi-pin lamps) of each rapid start lampholder/socket should be connected to each other or use "shunted" circle I lampholders/sockets for instant start bi-pin lamps. Always disconnect power before servicing installations and wire per the ballast schematics and National Electric Code.
- SYLVANIA ECOLOGIC fluorescent lamps are designed to pass the Federal Toxic Characteristic Leaching Procedure (TCLP) criteria for classification as non-hazardous waste in most states. TCLP test results are available upon request. Lamp disposal regulations may vary, check your local & state regulations. For more information, please visit www.lamprecycle.org